

- Assemble the two halves of the bubble tube bracket by lining up the slots in the angled piece with the holes in the other. Connect with the supplied nylon bolts and nuts. Hand tighten only at this point.
- Slide the bracket assembly over the bubble tube, and adjust the bracket until the angled edge is flat against one of the walls (your choice). The bracket should be mounted approximately 3" from the top of the bubble tube. Mark the location for on the wall for the anchors.
- The type of wall anchor needed depends on the construction of your wall (drywall, brick, wood, etc.). Make sure you are using the correct type of anchor for your wall type. Consult your maintenance personnel, or a compentant handyman as needed. Due to the variety of wall types, anchors are not included.
- Insert the anchors into the wall at the location marked, and fasten the wall bracket in place.
- Give the bracket a final fitting, and tighten the nylon nuts and bolts.

Manufactured proudly in the USA by:

Experia USA, Inc.

2880 McEver Road Buford, GA 30518 http://www.experia-usa.com

