Charging your Qi-enabled Controller (pronounced "Chee")

- 1. Your charger is equipped with a built-in wireless charging system and charging base.
- 2. Simply plug the supplied USB Charger into a wall outlet, and then plug the Qi charging pad into the wall charger.
- 3. Inside the controller is an inductive coil. This pulls electricity from the charging pad, which charges the battery. This coil is located directly under the RED button of the controller. Simply align the controller with the RED button directly over the charging pad, and set it down. The controller has an LED light that is RED when in standby mode (not charging), and green when charging. (this can be hard to see under the controller).
- 4. When successfully aligned, the green LED light (next to the red button) will illuminate. Simply leave in place to charge.
- 5. Just remove from the charger to use, and place back on the charger when not in use.

CAUTION: The USB wall charger supplied is rated at 2.0 Amps. This is critical for the safe and efficient charging of your wireless controller. If you use a different charger, it MUST be at least 2 Amps.

Troubleshooting

Q. The unit doesn't work.

A1. Is it switched on? If so,

A2. Has the unit scrolled through its colors? If so,

A3. Have you pressed a button on the 8 Button Wireless Controller? If so,

A4. Are the batteries in the 8-Button Wireless Controller fully charged?

If so, please contact us for further assistance.

Manufactured proudly in the UK by:

Experia

Acorn Phase 3, High Street, Grimethorpe Barnsley, South Yorkshire, S72 7BD United Kingdom

© Copyright 2010-2013 Experia All rights reserved. Experia is a registered trademark.

Contact Details

USA email: office@experia-usa.com

UK and rest of the world email: support@experia-innovations.co.uk

Telephone: (800) 882-4045







Congratulations on the pur-

The Superactive LED Bubble Wall has been designed specifically for people with special needs and should, if used in accordance with these guidelines, offer years of fun!

chase of your Superactive LED

Bubble Wall!

It comes complete with the 9-button wireless controller, which allows wireless control at a distance of up to 100 feet! Together they offer

opportunities to develop numerous skills including color recognition, cause and effect, and many more calming, relaxation and de-escalation opportunities.

It is the brightest LED Bubble Tube currently available (at time of print) and produces multiple shades of colors when used in calming mode.



For optimal results, please read and follow instructions carefully
Please keep for future reference



WARNING: CHOKING HAZARD

Small Parts: Not suitable for children under 3 years.



Features

- Ergonomic design
- Latest LED technology. No changing bulbs....EVER!
- Low voltage transformer supplied
- Easy maintenance
- Durable
- Easy to use
- 1 Year Manufacturers Guarantee (Collect and Return)

Pack contents

- 1 x Superactive LED Bubble Wall
- 1 x 9-button wireless controller
- 1 x Wall Mount Kit
- 1 x Drain/Fill Kit
- 1 x Low Voltage Transformer
- 1 x Qi** charging base
- 1 x USB wall charger
- ** Qi (pronounced "Chee"), is a wireless charging system

Getting Started

It is essential that the Experia Bubble Wall is not wall mounted but rests on the floor or a suitable load bearing surface with at least two wall brackets to prevent the unit falling forwards.

Enclosed with your Experia Bubble Wall you should find some brass mirrors plates (see images, below). These can be used to help secure the Experia Bubble Wall to a wall.

They will be either packed in a bag in the packaging or already fitted to the rear face of the Experia Bubble Wall (see images below).



Fig.1 – pre-attached mirror plate.



Fig.2 – Ready for wall mounting.

Fasteners for mounting to the wall are not included, as the type fastener needed will vary. Please ensure you select the appropriate fastener for your type of wall. Wall fasteners must be strong and secure to ensure the

weight of the Bubble Wall is stabilized. We recommend a minimum strength of 50 lbs. per fastener.

Once securely mounted to the wall, simply fill the bubble wall (see below), and plug in the XLR connector (right) from the transformer. Then, plug the transformer into a nearby 110v outlet.



Changing Bubble Wall Water

All bubble walls require the water in them changed every 4 – 6 weeks to slow the build up of any bacteria. The unique draining valve on the Experia Bubble wall makes this normally time-intensive task much quicker. We recommend you use a 2 gallon bucket

Emptying

- 1. Remove the white plastic cover at the bottom of the tank to reveal a valve.
- 2. Using the emptying hose which has a white
- 3. plastic male end, clip the male end into the valve and dip the other end of the hose into a clean empty bucket.
- 4. The water should flow out of the bubble wall on its own.
- 5. Once the water has finished emptying from the tank, empty the bucket in a suitable place.

Transfer Pump



Emptying Hose

Filling

- 1. Remove the white plastic cover at the bottom of the tank to reveal a valve
- 2. With the hoses attached to the Transfer Pump, locate the male end into the valve
- 3. Dip the end of the other Transfer Pump hose into a bucket of clean water
- 4. Push and pull the Transfer Pump plunger to start filling the Bubble Wall tank
- 5. Fill the tank until approximately 3/4 full

DO NOT FILL THE TANK ALL THE WAY! Once the

Bubble Wall is switched on the air displacement caused by the internal pump to create the bubbles

will cause the water level to rise. If the Bubble Wall tank is filled above ¾ full then water may leak from the top of the tank and cause internal damage

Modes of Operation

- Superactive mode is activated by using the 9 Button Wireless Controller to change the bubble wall's color, and to turn the bubbles on/off (black button).
- Calming mode is activated when the 9 Button Wireless Controller has been left dormant for 5 minutes. In this mode the color sequences automatically.

Please note: Only use the transformer supplied. Use of a different transformer may result in damage to the product and void the warranty.