

experia **usa**
multisensory for everyone



Superactive LED Bubble Tube

5600152

Product Manual

For optimal results, please read and follow instructions carefully.

Please keep for future reference.

Experia USA, Inc.
2880 McEver Road
Bldg. 1 - D
Buford, GA 30518
(800) 882-4045
info@experia-usa.com

experia
multisensory for everyone

Please follow all warnings on the product and within this manual. If upon receipt of this product, the user suspects that the product is defective, and/or requires service or repair due to malfunction or damage to the product, please contact the manufacturer immediately. Please be aware that improper installation and/or use or misuse of this product may result in injury, death, or adverse reactions to its user. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended uses of the product.

Features

- Ergonomic design
- Latest LED technology. No changing bulbs.....EVER!
- Qi Charging technology**
- Internal, rechargeable lithium-polymer battery - no batteries to change!
- Clear domed Lid and domed base
- Low voltage transformer – supplied
- Easy maintenance
- Durable & easy to use
- 1 Year Manufacturers Guarantee (Collect and Return)

Pack contents

- 1 x Superactive LED Bubble Tube
- 1 x Clear Domed Lid
- 1 x 9-button wireless controller
- 1 x Low Voltage Transformer
- 1 x Qi** charging base
- 1 x USB wall charger

** Qi is a wireless charging

Getting Started

1. Remove all packaging including clear film around the tube. Please note, the tube may contain a small amount of water, this is from our testing process, and completely normal.
2. Place the Calming Superactive LED Bubble Tube on a flat solid floor.
3. If the tube is over 60" high, secure the tube to a solid wall with a bubble tube bracket (sold separately) using the correct fasteners for your wall type.

Contact Details

For USA please email info@experia-usa.com.

Telephone: (800) 882-4045

Please note: email is our support team's preferred communication and this takes precedence over telephone calls.

Manufactured proudly in the U.S.A by:

Experia USA, Inc.

2880 McEver Road, 1 - D

Buford, GA 30518

© Copyright 2010-2013 Experia

All rights reserved.

Experia is a registered trademark.

WARNING: Never lift or move the bubble tube while full. It can damage the bubble tube and will void your warranty!



experia 
multisensory for everyone

Cleaning and Maintenance

The unit should be cleaned with a damp soft cloth. A non abrasive cleaning agent may be used for stubborn stains. Be sure no liquid enters the base of the unit.

The unit has been designed for use by people with special needs, however this does NOT mean it is unbreakable. You must be sure the unit is not hit with anything and that no one pulls or pushes the unit.

Changing Bubble Tube Water

All bubble tubes require that the water in them be changed every 6 – 12 weeks to slow the build up of any bacteria.

To change the water in an Experia LED Bubble Tube, please follow these instructions.

1. Remove the lid off the column.
2. Use a length of hose (4 yards minimum for a 80" column) to siphon the water out of the column into a bucket. Empty the bucket and repeat.

Note: We recommend wrapping a towel around the base of the clear column before removing the water. In the event of a spill, this offers a little extra protection against water entering the base.

Tip: To *make this process easier*, you can purchase an Experia pump kit online at www.experia-usa.com and type "pump" into the search box.

4. Carefully fill the bubble tube with water from the top. (**We HIGHLY recommend that you wrap the column in a blanket in case of an accidental spill.**) If you spill any water, please ensure this is cleaned immediately. Do not fill the tube to the top; allow 4 to 6 inches (150mm) from the water level to the top of the tube.
5. Connect the round XLR connector (silver connector with black cable (right) from the Low Voltage transformer to the socket in the base of the bubble tube.
6. Connect the adapter plug to a nearby outlet. The Bubble Tube will now illuminate and begin scrolling through many colors.
7. Press any of the colored buttons on the controller to change the color of the tube.
8. Press the black button in the center of the unit to stop and start the bubbles within the tube.



Modes of Operation

- **Superactive mode** is activated by using the 9 Button Wireless Controller to change the color of the bubble tube, and to turn the bubbles on/off (black button).
- **Calming mode** is activated when the 9 Button Wireless Controller has been left dormant for 5 minutes. In this mode the colors sequence automatically.

Please note: Only use the transformer supplied. Use of a different transformer may result in damage to the product and void the warranty.

Please turn to the next page to learn more about your Qi-controller.

Qi-enabled Controller

ON/OFF button: We ship the controller to you in the OFF position to prevent the battery from draining during shipping. The **FIRST** thing you must do is turn the button to the **ON** position. Once this is done, there will be no need (under normal circumstances) for you to ever turn it to the OFF position.

These controllers have an internal lithium-polymer rechargeable battery, which is charged wirelessly with the included charging pad.



Button Off



Button On

Your bubble tube may have been built a while ago (2-3 weeks), so it is possible - even likely - that the controller is in need of a charge. We recommend that you charge the controller for at least 4 hours, and preferably overnight, prior to the first use. After that, simply place the controller back on the charging pad at the end of every day, and you'll never need to replace batteries again!

Charging your Qi-Controller

Simply plug the supplied USB Charger into a wall outlet, and then plug the Qi charging pad into the wall charger.

Inside the controller is an inductive coil. This pulls electricity from the charging pad, which charges the battery. **This coil is located directly under the RED button of the controller.** Place the controller on top of the charging pad, aligning the **RED** button **directly over the charging pad**. The charging pad has an LED light that is illuminated with one color when not charging, and changes colors when charging. (this can be hard to see under the controller).

The controller itself has a green LED next to the red button. When successfully aligned, it will illuminate to indicate charging. You may need to slightly adjust the position of the 9-button controller a few times until it is correctly aligned and the charging light turns green. Then, simply leave it in place. **Note: If you do not have the on/off switch in the ON position, it will not charge.**

Simply remove the controller from the charging pad to use, and place back on the charging pad when not in use.

CAUTION: It is critical for the safe and efficient charging of your wireless controller that you use only the supplied USB wall charger.

Re-setting Your Qi-Controller

When the battery is completely discharged, OR when the controller is not used for some length of time, the safety circuit inside the battery can go into a default mode. When this happens, the battery can no longer "talk" to the circuit board, and your controller will not function properly.

If this happens, do the following:

1. Turn the power button on the side of the controller to the **OFF** position.
2. Count to 10.
3. Turn the power button back to the **ON** position.
4. Place the charger on the charging pad and charge the controller for at least 4 hours.

You can check to make sure the re-set worked after charging for 5 minutes. While **LEAVING THE CONTROLLER ON THE CHARGING PAD**, turn on the bubble tube and use the controller. It should now be functioning properly. If not, contact Experia USA for further troubleshooting help.